

FarSync Flex Firmware Update Procedure (Windows)

The *FarSync Flex* ships with at least a *Factory Default* version of firmware and may also ship with a later version; by default, the later version will always run. The *ffflash* tool allows a user to check, erase and reprogram the FLASH memory in the *Flex*.

The file to be downloaded to the *Flex* is usually named *ff_image_XXXX.hex*, where *XXXX* is the version number. The executable that downloads the code to the *Flex* is called *ffflash(.exe)*. In order to update the *Flex* you must have previously installed the *Flex* driver, then follow this procedure:

1. Copy the *ff_image_XXXX.hex* and *ffflash.exe* to a convenient folder on the host PC.
2. Attach the *Flex* and identify the SDCI number associated with it. This can be found from the *fsinfo* or *fsdemo* test applications (if you installed them), or direct from Device Manager under *FarSync WAN Adapters*.
3. Enter *ffflash -nSDCIx -iff_image_XXXX.hex* at the command prompt. Where "x" is the SDCI/sync number identified above and "XXXX" is the version number of the supplied file.
4. Enter "C" to check the current FLASH content. You should see something like this:

```
C:\Temp>ffflash -nSDCI3 -iff_image_0208.hex

FFFlash Version 1.1.0

Path: \\.\SDCI3\0

FarSync Flex FFFlash Version 1.1.0
Copyright FarSite Communications Ltd. 2013

C.....Check
E.....Erase
P.....Program

Select C, E or P. Q to Quit

Block  Address  Version  Status  Attribute
0      0x00000    . . .   used    r-x-
1      0x04000    . . .   used    r---
2      0x06000    . . .   free    r---
3      0x08000    . . .   used    r-x-
4      0x10000    . . .   used    r-x-
5      0x20000    0.2.0.8 used    r-x-
6      0x30000    . . .   used    rwx-d
7      0x40000    . . .   free    rwx-d
8      0x50000    . . .   free    rwx-d
9      0x60000    . . .   free    rwx-d
10     0x70000    . . .   free    rwx-d
```

5. FLASH Block 5 will always contain the Factory Default code, Blocks 6 – 10 may be free or could already contain other versions. Blocks 0 – 5 are write-protected and cannot be erased. In order to download a new version there must be at least one free block available. If necessary, one or more blocks can be erased to make space at this stage. To erase a block, enter "E" and select the block to be erased.

Firmware versions 0.2.0.0 and later require 2 adjacent blocks. If you request fflash to erase a block containing part of a firmware image then the complete image will be erased.

6. Now, program the new code by entering "P" and selecting the destination starting block number. You should see something like:

```
Enter Block to Program (0...10): 7
Programming FLASH (block 7 @ 0x00040000)
File                ff_image.hex
Start Address       0xFFFFFFFF
Checksum            0xFFFFFFFF
FLASH minAddress    0x00000000
FLASH maxAddress    0x00014ADF
FLASH used          84704 bytes
FLASH flashAddress  0x00040000
FLASH flashEndAddress 0x00060000
```

7. If you enter "C" again you should see the new code in the selected destination Block:

Block	Address	Version	Status	Attribute
0	0x00000	. . .	used	r-x-
1	0x04000	. . .	used	r---
2	0x06000	. . .	free	r---
3	0x08000	. . .	used	r-x-
4	0x10000	. . .	used	r-x-
5	0x20000	0.2.0.8	used	r-x-
6	0x30000	. . .	used	rwxd
7	0x40000	0.3.0.0	used	rwxd
8	0x50000	. . .	used	rwxd
9	0x60000	. . .	free	rwxd
10	0x70000	. . .	free	rwxd

8. Enter "Q" to quit, then unplug and replug the *Flex* to activate the new code.

9. The updated *Flex* can now be run under *Windows* or *Linux* as desired.