



## X.Port Xi+ X.25 Adapter Jumper Settings

A combination of jumpers at the four positions in jumper block J6 are used to set the Memory Address and Memory Window Size as shown below:

### 32k Memory Window



### 16k Memory Window



The memory window location is given as its segment address, in hexadecimal notation. A 32k window at D000, for example, will occupy addresses from D0000 to D7FFF inclusive.

A 32k memory window allows faster data transfer to/from the card, but the 16k window may be necessary in a machine in which several adapters are already installed. Note that some software drivers do not support the 16k window size - refer to the product documentation for further information.