

## Regulatory Notices

### EC Declaration of Conformity

FarSite Communications Limited declare that the products FarSync T2Ue and T4Ue are in conformity with the following standards and other documents:

Telecommunications Terminal Equipment (TTE Directive 91/263/EEC): **TBR1, TBR2**  
Electromagnetic compatibility (EMC Directive 2004/108/EC): **EN55022, EN61000-6-2**  
Safety (LVD Directive 2006/95/EC): **EN60950**



This equipment is intended for attachment to public or private leased lines or packet switched data networks.

### Federal Communications Commission (FCC) Statement

#### Radio Frequency Interference (RFI) (FCC 15.105)



This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by switching the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

#### Labelling requirements (FCC 15.19)

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference which may cause undesired operation.

#### Modifications

Changes or modifications to this equipment not expressly approved by FarSite may void the user's authority to operate this equipment.

### FCC Declaration of Conformity

(In accordance with FCC docket 96-208 and 95-19)

Manufacturer's name: FarSite Communications Limited  
Tempus Business Centre, 60 Kingsclere Road, Basingstoke  
Hampshire, RG21 6XG, United Kingdom

FarSite Communications Limited declares that the product FarSync T2Ue and T4Ue to which this declaration relates, meet the requirements specified by the Federal Communications Commission as detailed in the following specifications

- Part 15, Subpart B, for Class B Equipment
- FCC Docket 96-208 as it applies to Class B Personal Computers and Peripherals

The products have been tested at an external laboratory certified per FCC rules and has been found to meet the FCC, Part 15, Class B emission limits. Documentation is on file and available from FarSite.

## Industry Canada

This Class B digital apparatus meets the requirements of the Canadian Interference Causing Equipment regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

# FarSite

## COMMUNICATIONS

### FarSync T2Ue/T4Ue

## QUICK START GUIDE

### FOR WINDOWS AND LINUX

Thank you for choosing FarSync for your synchronous data communications needs. The FarSync product family provides a full range of synchronous data communications solutions. There are 1, 2 and 4 port versions with support for balanced and unbalanced signal types. The models covered by this guide are:

#### FarSync T2Ue

An intelligent 2-port PCI-Express adapter for synchronous data communications over X.21 (V.11/RS-422), V.24 (X.21bis/RS-232-C), V.35 and similar physical interfaces.

#### FarSync T4Ue

An intelligent 4-port PCI-Express adapter for synchronous data communications over X.21 (V.11/RS-422), V.24 (X.21bis/RS-232-C), V.35 and similar physical interfaces.

Please refer to cable application details at [www.farsite.com](http://www.farsite.com) for the latest available information.

The installation of the FarSync T2Ue/T4Ue product has three basic steps.

- **Install the hardware**
- **Connect the cables**
- **Install and configure the FarSync driver software**

Refer to page 2 of this guide for more instructions on each step. Note that **Administrative privilege** is required to install the software under Windows. Installation under Linux should be performed as **root**. Use a web browser to view the file `|install.html` file for further assistance on the installation process.

Manuals on the FarSync CD are in HTML or Adobe Portable Document Format (PDF). If you do not already have a suitable PDF reader installed a selection of readers can be found in the **Acrobat** directory on the FarSync CD. Further readers for other platforms are available from Adobe.

Step 1 Installing the hardware

**Warning – Electrostatic discharge can damage integrated circuits on your FarSync card. Observe precautions for handling electrostatic sensitive devices.**

Shut down and power off the system. Identify a free PCI Express slot in your PC and install the FarSync T2Ue or T4Ue card, ensuring that it is properly secured with a mounting screw. The FarSync T2Ue and T4Ue cards are **PCI Express** cards that will operate in any PCI-Express (PCIe) slot conforming to revision 1.0a or later of the PCI Express specification. This includes slots with x1-lane, x4-lane, x8-lane and x16-lane connectors.

Step 2 Connecting the cables

The FarSync T2Ue card has two 26-pin high density D-type female connectors marked A and B to distinguish the ports. The FarSync T4Ue card has a single 62-pin high density D-type female connector.

The card is connected to the Network Termination Point with an adapting cable compatible with the Network Termination Unit (NTU).

FarSync T2Ue


The most commonly used serial interface cables are as follows (other cables are available):

Cable	Serial Network Connection
UCR1	25 pin D-type male connector for V.24 (X.21bis/RS-232-C) use.
UCX1	15 pin D-type male connector for V.11 (X.21/RS-422) use.
UCV1	MRAC-34 male 'brick' type connector for V.35 use.

The 26-pin connector should be firmly secured to the communications card using the screws in the connector hood. The connection to the Network Termination Point should be firmly secured in a similar way.

FarSync T4Ue - Single Unit Cable Assembly

The first possible arrangement uses a single unit cable assembly with 4 serial interface connectors that connect directly to the Network Termination Point.




The most commonly used serial interface cables are as follows (other cables are available):

Cable	Serial Network Connection(s)
MCR4	Four 25 pin D-type male connectors for V.24 (X.21bis/RS-232-C) use.
MCX4	Four 15 pin D-type male connectors for V.11 (X.21/RS-422) use.
MCV4	Four MRAC-34 male 'brick' type connectors for V.35 use.

FarSync T4Ue - Modular Cable Assembly

The second possible arrangement uses a modular set of cables consisting of a transition cable (type **MTU4**) to provide four High Density 26-pin male connectors that are each then adapted to the required serial interface connector type with additional serial interface cables (Diagram shows a 4 port **MTU4** cable).



The available serial interface cables are as shown for the FarSync T2Ue on page 2.

The 62-pin connector of the **MTU4** cable should be firmly secured to the communications card using the screws in the connector hood. The connections between the transition cable and the serial interface cable(s) and the connection to the Network Termination Point should be firmly secured in a similar way.

Step 3 Install and Configure the Driver Software

The software included with this product is subject to one or more software license agreements. The top level license agreement is either included in printed form in your product package or in the file LICENSE.TXT in the root directory of the CD included with the product.

**By installing the software you agree that you have read and understood the license and agree to its terms and conditions**

The driver installation varies between the different supported operating systems, but in all cases the hardware should be installed first. **Note: For installations on Microsoft Windows Operating Systems, System Standby must be disabled** . Refer to the software CD or the FarSite web site for the latest information on supported environments.

Driver installation and configuration instructions for each supported operating system can be found on the software CD accompanying the product. The `install.html` file in the root directory of the CD should be used as a starting point.

WARRANTY INFORMATION

Your FarSync T-Series adapter carries as standard a return to base hardware warranty of 5 years from date of delivery. If you require support visit the Support area at [www.farsite.com](http://www.farsite.com). If you wish to extend your warranty period or upgrade to full product maintenance cover, please contact your sales representative. Further information can be found at [www.farsite.com/products/product\\_warranty.htm](http://www.farsite.com/products/product_warranty.htm).